



CARE INSTRUCTIONS

Removable Covers

Follow the washing recommendation on the label inside the cover.

Fixed Covers

For cleaning the upholstered surface, first try to brush off the dirt gently. If this is not enough then vacuum the surface. If further cleaning of the padding is needed, a stain remover is recommended. The cleaning has to be gentle and must always be tested on the most invisible area of the surface before the actual cleaning. Avoid blotches by gentle, circular rubbing towards the stain.

To avoid stains, quickly remove the dirt with a piece of absorbing household wipe and clean with water and colourless washing-up liquid.

Do not use the following products for the padding:

- Undiluted cleaning liquids.
- Bleach.
- Ammoniac.
- Soap for hard surfaces.



For enquiries contact GUBI A/S - CVR: 17940384
Klubiensvej 7-9. 2150 Nordhavn. Copenhagen, Denmark
T +45 69 15 60 60 – order@gubi.com
GUBI.COM


69-20-010-01 Assembly Instructions Wonder Sofa.

GUBI

ASSEMBLY INSTRUCTIONS


for

Wonder Sofa






1. Assembly

Flip the pin out from underneath the base.



2.

Place the modules next to each other and slide them together, connecting the ratchet joints.



3. Disassembly

Tilt the module up from the front.

