


GUBI


ASSEMBLY INSTRUCTIONS

for


Seine Ceiling Lamp




CONTENTS



x1



x1



x1




x2





x2

1.

Using the two supplied screws, mount the ceiling bracket (a) depending on the ceiling material.
Wire the lamp (b).
Connect the canopy to the bracket with the two supplied screws (c).




b)



2.

Insert the G9 bulb (not included) into the socket
insert the shade and rotate it to fix it with the base





CARE INSTRUCTIONS

Daily cleaning can be done by wiping the glass and base with a clean dry cloth. Should the surface need more attention this can be cleaned with water and a light detergent or soap applied with a damp cloth. Wipe after with a clean dry cloth. Avoid any abrasive materials.

TROUBLESHOOTING

If lamp does not light, turn off the power. Check the bulb for a broken filament. Replace bulb if necessary, then turn it on. If the lamp still does not light, please contact customer service at the local dealer. If the external flexible cable or cord of this lamp is damaged, it must be replaced by a qualified electrician in order to avoid a hazard.

TECHNICAL INFORMATION

Light sources: G9, 470 Lumen (Max 6W LED). Turn power off when changing light bulb.
Isolation class II. The lamp is not approved for outdoor use in damp/wet rooms (IP20)

ENVIRONMENTAL PROTECTION

Electrical products must NOT be thrown out with domestic waste. They must be taken to a communal collecting point for environmentally friendly disposal in accordance with local regulations. Contact your local authorities or retailer for advice on recycling. The packaging material is recyclable. Dispose of the packaging in an environmentally friendly manner and make it available for recyclable material collection-service. Do not incinerate.



For enquiries contact GUBI A/S - CVR: 17940384
Orientkaj 18-20, 2150 Nordhavn, Copenhagen, Denmark
T +45 69 15 60 60 – order@gubi.com
GUBI.COM